

LBX SIGN LIGHTER


INSTALLATION INSTRUCTIONS



WARNING: ALWAYS INSTALL FIXTURES ACCORDING TO NATIONAL ELECTRICAL CODE (NEC) AND LOCAL CODES. FAILURE TO DO SO WILL VOID THE WARRANTY AND COULD CAUSE DAMAGE TO THE FIXTURE OR MAY RESULT IN PERSONAL INJURY.

IMPORTANT: TURN ELECTRICITY OFF AT THE CIRCUIT BREAKER BEFORE INSTALLING OR PERFORMING MAINTENANCE ON FIXTURE.


This information deals with structures supplied by Techlight along with certain safety issues. It is **NOT** a comprehensive description of how to install these structures. Installation contractors must be relied upon for equipment and practices that meet the conditions of each job location. Techlight cannot be responsible for any damage that may occur during or after installation, or for any structure that has been modified by the purchaser or that is used in some way other than our application recommendations.




⚠ CAUTION: MAKE CERTAIN POWER SUPPLY IS DISCONNECTED DURING INSTALLATION!

LEVELING

- It is the contractor's responsibility, not TechLight, to maintain a level pipe and luminaire, and to ensure that the pitch and angle of the luminaire is zero.
- In the pipe chamber, there are two linear-level-bubbles, attached to the heat sink, to assist the contractor in assuring that the luminaire is level.





LLBIDE Remote Driver Housing



LBX SIGN LIGHTER INSTALLATION INSTRUCTIONS



MOUNTING ACCESSORIES

Interior Thru Wall Support Square Plate Heavy Duty - 132406XX





Interior Thru Wall Plate

Exterior Beauty Plate for Regular Arms < 60" - 132408XX




Exterior Fascia Plate

Exterior Thru Wall Support Round Plate for Long Arms > 60" - 132409XX




Exterior Thru Wall Plate



LBX SIGN LIGHTER INSTALLATION INSTRUCTIONS

COMPLETED INSTALATION STRAIGHT ARM



COMPLETED INSTALATION OFFSET ARM

